



Handling Instructions for Bally White or Sand Tan Polyester Finishes

This finish is one of the most durable painted surfaces available today, and normally is supplied with a protective covering. Below are proposed procedures for handling Bally Polyester panels.

Caution should be exercised when handling painted panels with or without the protective coating. Panels protected with the film should not be stored or exposed to the sun for extended periods of time. For convenience, Bally has cut the covering around the perimeter of the panel to allow materials to be more easily removed. Never use putty knives, knives or scrapers on painted surface. Install all panels carefully.

The strippable protective covering

Remove the protective covering only after the installation has been completed. To remove the coating start at one corner of the panel and pull back the strippable material. For best results pull strippable material back uniformly, applying pressure throughout. This will allow removal of large areas without a tear.

Plug buttons are provided for Speed-Lok holes. Floors and unpainted areas require stainless steel plug buttons. Plug buttons are to be inserted by hand.

For the convenience of the installer, a spray can of touch-up paint is provided. Follow the instructions on the can for proper use.