

## Field Installation of the Kason 1092 Door Closer

1. Locate horizontal center-line of the door closer casing, as shown below. Keep the top of the closer flush with the side of the door. Caution: Do not use the holes to the left of the clearance line.
2. Secure hook to door frame, mount with #8 self-tapping screws in slotted holes. Check the adjustment, roller should touch and revolve slightly as it meets the hook. (See Figure 2.)
3. Fasten hook with remaining screws.
4. Complete assembly of door closer by attaching cylinder to casing and lever, using pins provided.
5. After assembly extend roller lever fully towards the walk-in (Figure 2). Door closer is ready to operate.

