



Speed-Lok Plate in Wood Floors

NOTES:

1. Attach hole covers after the walk-in is completely erected, before the plywood is covered.
2. Bally recommends use of ½" -1" brads to hold the Speed-Lok hole cover in place until finished flooring is set.
3. Make sure Walk-In is properly ventilated until finished floor is completely dry.

