

Mounting instructions for façade trim on a membrane roof

After membrane roof installation:

1. Install interior façade trim as shown using #12-14 x 1½" tek screws (screws to match finish). See figure 1.
2. Install exterior façade trim as shown by forcing the hook flange behind the interior façade trim. Attach bottom of exterior façade (and drip edge if applicable) with #12-14 x 1½" tek screws (finish to match exterior). See section a-a.
3. Install corner plug trim as shown using (4) 1/8" pop rivet (finish to match exterior). See figure 2.
4. After all façade trim pieces are installed caulk the seam between roof and façade trim. Section a-a.

DO NOT MAKE ANY PENETRATIONS THROUGH TOP OF MEMBRANE ROOF. SEE IM-91-338.

